

## Woodura® Hardened Wood

### COMMERCIAL MAINTENANCE PROCEDURES

#### DURING INSTALLATION

Place walk off mats at entrances to minimize dirt & grit being tracked on the floor  
Do not slide heavy items across the floor Frequently: sweep, vacuum

#### IMMEDIATELY AFTER INSTALLATION & BEFORE GENERAL USE

- Protect the entire floor, covering from wall to wall. (i.e. with Ram Board)
- When the protective covering is removed, sweep then vacuum (using a soft bristle brush head- this is the most effective means to remove any drywall dust)
- Install felt-type floor protectors on all furniture and any objects that may be frequently re-positioned by the end user.
- Clean the floor as noted below

#### ROUTINE MAINTAINANCE

- Place walk-off mats at all entrances.
- Sweep or vacuum (never use a beater bar!) after daily use
- As needed: Use a microfiber mop, clean the floor using Bona Kemi's Hardwood Floor Deep Cleaner (recommended) or other cleaner made specifically for hardwood floors. Be mindful to replace the mophead as it gets dirty, change.
- Note: microfiber mops can be washed and re-used.
- Clean and replace felt furniture protectors as needed

#### PERIODIC DEEP CLEANING

- Sweep, then vacuum the entire floor
- Using a 175 RPM buffer with a white polishing pad, lightly mist 8' X 8' sections and buff the floor
- Immediately following: use a microfiber mop lightly dampened with water to remove any remaining dirt/grit
- Move to the next section and repeat
- Replace the white pad and microfiber pad as they appear soiled

#### RECOATING YOUR FLOOR

Eventually, the floor will need to be re-coated to return the full luster. This does NOT void your commercial warranty! We recommend Bona Kemi's Waterborne finishes such as Bona Traffic GO which has a similar sheen to our factory finish.

Contact Bona Kemi: [www.bona.com](http://www.bona.com) or 800-872-5515 for a professional near you



**Planet-Approved. Engineered to Last.™**

[endurematerials.com](http://endurematerials.com) 866-631-2221